

TWR Lighting, Inc.

4300 WINDFERN RD. SUITE 100 HOUSTON, TX 77041-8943

VOICE (713) 973-6905 FAX (713) 973-9852

WEB: twrlighting.com

IMPORTANT!!!

PLEASE TAKE THE TIME TO FILL OUT THE FORM COMPLETELY. FILE IN A SAFE PLACE. IN THE EVENT YOU EXPERIENCE PROBLEMS WITH OR HAVE QUESTIONS CONCERNING YOUR CONTROLLER, THE FOLLOWING INFORMATION IS NECESSARY TO OBTAIN PROPER SERVICE AND PARTS.

MODEL #

D-1LVS

SERIAL #

PURCHASE DATE

PURCHASED FROM

D-1LVS CONTROLLER

TABLE OF CONTENTS

1.0	INTRODUCTION.....	1
1.1	APPLICATION.....	1
1.2	SPECIFICATIONS OF EQUIPMENT	1
2.0	INSTALLATION.....	2
2.1	POWER SUPPLY CONTROL CABINET MOUNTING	2
2.2	PHOTOCELL HOUSING	2
2.3	PHOTOCELL WIRING	2
2.4	POWER WIRING.....	3
2.5	TOWER LIGHTING KIT.....	3
	2.5.1 Beacon Mounting.....	3
	2.5.2 Lighting Kit Wiring.....	4
2.6	ALARM WIRING.....	4
	2.6.1 Alarm testing	4
	2.6.2 Strobe Failure (SF).....	4
	2.6.3 Power Failure (PF)	4
	2.6.4 Photocell (PC)	5
2.7	CONTROLLER CONFIGURATION.....	5
3.0	THEORY OF OPERATION	6
3.1	THE POWER SUPPLY.....	6
3.2	THE FLASHTUBE	6
3.3	TIMING CIRCUIT	7
3.4	TRIGGER CIRCUIT.....	7
3.5	ALARM CIRCUITS	7
	3.5.1 Strobe Failure (SF)	7
	3.5.2 Photocell (PC).....	7
3.6	BLEEDER CIRCUIT	8
3.7	STROBE DIAGNOSTIC CIRCUITS	8
	3.7.1 Control Power On	8
	3.7.2 High Voltage	8
	3.7.3 Trigger Voltage	9
	3.7.4 Nightmode	9
	3.7.5 Primary Timing.....	9
	3.7.6 Timing Signal Verify.....	9
	3.7.7 Flash Verified.....	9
	3.7.8 Strobe Fail Test	9

D-1LVS CONTROLLER

4.0	TROUBLE SHOOTING	10
4.1	TOOL REQUIREMENTS	10
4.2	DIAGNOSTIC EVALUATION	10
4.3	TROUBLE SHOOTING ASSISTANCE.....	11
4.3.1	Flash Verify LED - Out.....	11
4.3.2	Control Power On LED - Out	11
4.3.3	Primary Timing LED Out.....	11
4.3.4	False or Nonexistent Beacon Alarms	12
5.0	MAINTENANCE GUIDE.....	13
5.1	FLASHTUBE REPLACEMENT	13
5.2	POWER SUPPLY.....	13
5.3	PHOTOCELL.....	13
6.0	MAJOR COMPONENTS PARTS LIST	14
7.0	RECOMMENDED SPARE PARTS LIST.....	16
	PRODUCT WARRANTY.....	17
	RETURN POLICY	18
	RETURN GOODS AUTHORIZATION FORM (RGA).....	19

D-1LVS CONTROLLER

APPENDIX

Chassis Layout.....	H40-283
Wiring Diagram	M01-283
Housing Details D-1LVS.....	HD0-283
Installation Guideline	INS-283
Photocell Housing Detail	100239
Tower Lighting Kit - Cable	500-12
Control PCB #1	H01-226B
High Voltage Rectifier PCB #2	H02-226A
Relay PCB #3.....	H03-226
Strobe Beacon Detail	100437M

D-1LVS CONTROLLER

1.0 INTRODUCTION

TWR Lighting Division's Model D-1LVS Type L-865 Controller has been designed and built to the Federal Aviation Administration's (FAA) Advisory Circular 150/5345-43E with safety and reliability in mind. TWR is committed to providing our customers with some of the best products and services available. TWR welcomes you to our family of fine products and we look forward to servicing your needs now and in the future.

1.1 APPLICATION

The D-1LVS L-865 Controller is for use on lighting structures or towers that are approved to be lighted with Medium Intensity Strobes in accordance with the FAA's Advisory Circular 70/7460-1K. Structures from 201' to 350' may be lighted with Medium Intensity lights. **NOTE: Structures exceeding 500' will require to be painted in addition to this lighting for added visual hazard marking.**

1.2 SPECIFICATIONS OF EQUIPMENT

Dimensions:

Controller (HxWxD)/Weight	18.0"x16.0"x9.25"	45.0 lbs.
Mounting Dim (HxW)		18.74"x12"
Beacon Height/Weight	17.25"	21 lbs.
Cable Diameter/Weight Per 100 ft.	.625" +/- 10%	24 lbs.
Electrical	120V AC +/- 10% 60 Hz (Standard)	
	240V AC +/- 10% 60 Hz (Available)	

Intensity:

Daymode	20,000 +/- 25%	Effective Candelas
Nightmode	2,000 +/- 25%	Effective Candelas

Beamspread:

Horizontal	360°
Vertical	3° minimum

Flash Rate:

Daymode	40 fpm +/- 2 fpm
Nightmode	40 fpm +/- 2 fpm

Wattage:

Daymode	95 Watts
Nightmode	35 Watts

Temperature:

+55°C / -55°C

D-1LVS CONTROLLER

2.0 INSTALLATION

2.1 POWER SUPPLY CONTROL CABINET MOUNTING

The power supply control cabinet can be located at the base of the structure or in an equipment building. Mounting Dimensions can be found in Section 1.2 on page 1. Pay particular attention when choosing your controller mounting location to ensure proper door opening and room for service personnel. Refer to installation drawing HDO-283 for ease of install.

2.2 PHOTOCELL HOUSING

The standard photocell housing is supplied with a 20' pigtail of 16 AWG Type TFFN wire. On occasion, in mounting of the photocell, an additional amount of wire may be required. Refer to drawing 100239 for proper assistance on determining gauge of wire for your specific needs.

2.3 PHOTOCELL WIRING

(Refer to Drawings HD0-283 and H40-283)

If the control cabinet is mounted inside an equipment building, the photocell should be mounted vertically on ½" conduit outside the building above the eaves facing north. Wiring from the photocell housing socket to the control cabinet should consist of one each; red, black, and white wires. The white wire is connected to the socket terminal marked "COM", the black wire is connected to the socket terminal marked "B", and the red wire is connected to the socket terminal marked "R". These socket connections are made by using .25" quick connect terminals, which must be crimped to the wires. The photocell should be positioned so that it does not "see" ambient light, which would prevent it from switching to the nightmode.

If the control cabinet is mounted outside an equipment building, the photocell should be mounted vertically on ½" conduit so the photocell is above the control cabinet. Care must be taken to assure that the photocell does not "see" any ambient light that would prevent it from switching into the nightmode. The photocell housing socket wiring is the same as above.

2.3.1 Connect the **BLACK** wire from the photocell to TB1-8.

2.3.2 Connect the **RED** wire from the photocell to TB1-6.

2.3.3 Connect the **WHITE** wire from the photocell to TB1-7.

D-1LVS CONTROLLER

- 2.3.4 Install the photocell into the receptacle and twist to the right while depressing to lock into place.

Note: *When installing multiple controllers together, the photocell is only required on one (1) unit. It can be installed on the master (or) slave. SSR interconnect wire must be common to all units. D2/3LV SSR TB3-2 / D-1LVS SSR TB1-6.*

2.4 POWER WIRING

(Refer to Drawing H40-283)

Power wiring to the control cabinet should be in accordance with local methods and the National Electric Code (NEC).

- 2.4.1 A 15 amp circuit breaker is recommended at service panel.
- 2.4.2 Connect the “**HOT**” side of the 120V AC line to TB1-9.
- 2.4.3 Connect the “**NEUTRAL**” side of the 120V AC line to TB1-10.
- 2.4.4 Connect the AC ground to the ground stud to the lower right of the terminal block TB1.
- 2.4.5 Controller panel should be connected to tower and/or building grounding system with the exception of installations on AM/RF Applications where controller grounding to earth ground is prohibited. Ground the controller only to the tower itself using a suitable RF ground.

2.5 TOWER LIGHTING KIT

When installing this system, the customer will need to use strobe cable to wire the strobe beacon. Refer to Lighting Kit Drawing 500-12 for cable installation.

2.5.1 Beacon Mounting

(Refer to Drawing HDO-283)

- 2.5.1.1 Bolt the beacon to the mounting plate using four 5/8" x 1 1/2" galvanized bolts that are supplied. Installer should make sure to check for full thread engagement on Anco locknut. Allow 18" clearance in back of the hinge (25" from the center of the base) to tilt lens back without hitting an obstruction.
- 2.5.1.2 Level the beacon using the level at the base of the lens. Shims may be used under beacon base or triple nutting each bolt with palnuts on all four (4) nuts.

D-1LVS CONTROLLER

C:\Documents and Settings\esalazar\Local Settings\Temporary Internet Files\OLK19\D-1LVS Rev 040903.doc
5/19/2003

12/98; Rev. 6/99; Rev. 03/00; Rev. 05/00;
Rev. 07/07/00 (dwg H01-226B); Reg. 07/08/00 (Pg. 9, DSI);
Rev. 07/00 (o2L/H); Rev. 10/18/00 (retyped & o2-dwgs.)
Rev. 05/14/01 (revised pg 1 – mounting width; warranty & return policy)
Rev 03/20/03 (TWR logo – Dwgs) Rev 04/09/03

D-1LVS CONTROLLER

2.5.2 Lighting Kit Wiring

Install wiring between the controller to the beacon utilizing either strobe cable method. **(TWR LIGHTING CANNOT WARRANTY SYSTEMS THAT EMPLOY SPLICING CABLE.)** Refer to drawings HDO-283 and 500-12 for install of lighting kits. Follow these minimum guidelines as well as any local or end user addition requirements. Installing lighting kits will require lifting of the cable by the supplied cable grip or conduit to affix to the tower. Always work safely and adhere to all OSHA Safety Guidelines when lifting wiring or working on the structure or tower itself. It is the installer's responsibility to install the lighting kit in a safe manner. Installers can request from OSHA their requirements 29CFT 1926.21 and 29CFR 1926.105 to ensure compliance to regulations.

NOTE: *On occasion a set of custom lighting kit drawings may be specifically requested by a customer and installed in this manual. In cases such as this, the drawings will precede the manual if a conflict occurs.*

2.6 ALARM WIRING

Individual alarm contacts (Form C) are provided for strobe failure, power failure and photocell on. It is left up to the customer or installer on how they choose to utilize these contacts with their monitoring equipment. Alarm configurations are shown on drawing H40-283.

2.6.1 Alarm testing

To test alarms, follow these procedures using an "ohm" meter between alarm common and alarm points.

2.6.2 Strobe Failure (SF)

Strobe failure testing can be performed in either day or nightmode strobe operation. Check for status of strobe beacon. Turn on switch S1 on PCB #1 and status should change after an eight (8) second delay. After test, switch S1 to normal operating position.

2.6.3 Power Failure (PF)

While the controller is in normal operation, shut off power to the controller at the breaker panel. Alarm should be prompt. Reset breaker to resume normal operation.

2.6.4 Photocell (PC)

Controller should be in the daymode of operation when performing this test. Check status of operation. Turn SW3 on or cover the photocell and alarm

D-1LVS CONTROLLER

status should change state. After test turn SW3 to normal operating position.

2.7 CONTROLLER CONFIGURATION (Refer to Drawing H01-226B)

This unit is factory set-up to be a master controller. If this unit is to be used in conjunction with an additional unit, change dipswitch settings (DS1) as drawing indicates.

- 2.7.1 Connect at least an 18/20 gauge wire from master unit D2/3LV PCB 1-15 (TS) to slave unit D2/3LV PCB1 P1-15 (TS) or D-1LVS PCB1 P1-15 (TS).
- 2.7.2 Connect at least an 18/20 gauge wire (ground) from one chassis to the other chassis.
- 2.7.3 Use a single breaker for supply power to all controllers.
- 2.7.4 Follow standard instructions provided in the manuals supplied with the controllers.

D-1LVS CONTROLLER

3.0 THEORY OF OPERATION

3.1 THE POWER SUPPLY

The AC line is sent to transformer T1 through fuse F1 and relay K1. In order for K1 to energize and complete the circuit to T1, the safety interlock switch CSS, BSS, must be closed. The BSS switch is located in the base of the beacon. In order for the system to operate, the beacon and the power supply must be closed and secured.

Transformer T1 secondary output is around 1,000V AC. These outputs are sent to the high voltage rectifier PCB (PCB #3) and converts the 1,000V AC of the transformer to around +500V DC and -500V DC in daymode and +700V DC and -550V DC in nightmode. This high voltage is then used to charge the energy storage capacitor C102 through current limiting resistor R31 steering diode D5 for nightmode operation. Resistor R31 is by-passed through relay K5 for daymode operation.

Energy storage capacitors bank C103-109 is used for the daymode operation and are connected to the high voltage through the normally closed contacts of relay K5. When the light level drops below 3-foot candles, the photocell supplies 120V AC to relay K5, which removes C103-109 from the discharge path leaving capacitor C102 in the circuit for nightmode operation.

The energy storage capacitor bank is connected to the flashtube through the interconnecting tower wiring.

3.2 THE FLASHTUBE

The flashtube FT is a quartz tube containing two (2) electrodes each. The electrode at the positive (+) end is called the Anode and is connected to the positive side of the storage capacitors through inductor L1. The electrode at the negative (-) end of the tube is called the Cathode and is connected to the negative side of the energy storage capacitors banks.

The flashtube contains a gas called Xenon. When the high voltage energy in the storage capacitors is connected to the flashtube, nothing will happen since Xenon in its natural state is not a conductor of electricity. However, when a very short duration high voltage pulse is impressed on the trigger element of the tube (via the power supply and trigger transformer T4) the Xenon gas is ionized and thereby becomes a good conductor of electricity. This allows the electrical energy in the storage capacitors to discharge rapidly through the flashtube, which converts this energy to light energy and heat energy. When the voltage stored in the capacitors discharges to a low level the Xenon gas can no longer sustain conduction and since the short trigger pulse is gone by this time, it deionizes returning to its non-conducting state until another trigger pulse arrives to repeat the process. Meanwhile, the storage capacitor is being recharged by the transformer and the high voltage rectifier.

D-1LVS CONTROLLER

C:\Documents and Settings\esalazar\Local Settings\Temporary Internet Files\OLK19\D-1LVS Rev 040903.doc
5/19/2003

12/98; Rev. 6/99; Rev. 03/00; Rev. 05/00;
Rev. 07/07/00 (dwg H01-226B); Reg. 07/08/00 (Pg. 9, DSI);
Rev. 07/00 (o2L/H); Rev. 10/18/00 (retyped & o2-dwgs.)
Rev. 05/14/01 (revised pg 1 – mounting width; warranty & return policy)
Rev 03/20/03 (TWR logo – Dwgs) Rev 04/09/03

D-1LVS CONTROLLER

3.3 TIMING CIRCUIT

The timing circuit is contained entirely on printed circuit board #1. The timing circuit has its own power supply. This circuit converts the AC line voltage to approximately 12V DC, which is used to supply all of the components in this circuit. It uses this low voltage DC to generate pulses that control the flash rate of the flashtube. It actually generates two (2) groups of pulses. The first is a pulse approximately once every 1.4 seconds to operate the flashtube during the daylight hours. The second is a burst of 10 or more very rapid pulses (to elongate the apparent flash) every flash to operate the flashtube during the nighttime hours at reduced flash energy.

3.4 TRIGGER CIRCUIT

The trigger circuit is supplied by one (1) of transformer T1's secondary windings. The 300V AC is converted to DC, which is stored in a storage capacitor much like the action of the high voltage circuit. The main difference is that the storage capacitor is much smaller. The trigger circuit receives the pulses generated by the timing circuit. It releases its stored energy with each pulse and delivers it to the flashtube's trigger element to initiate each flash.

3.5 ALARM CIRCUITS

3.5.1 Strobe Failure (SF)

Strobe Failure alarm circuit monitors each flash of the flashtube within each beacon. If the flashtube fails to flash (for any reason), the alarm circuit operates a relay (on PCB #1) that the customer can connect to their alarm transmitting devices. The alarm point can be accessed on J2 on PCB #1.

The power failure alarm relay is energized during normal operation. Should the power be removed for any reason, then relay K6 would drop, creating an alarm for the customer alarm transmitting device.

3.5.2 Photocell (PC)

The photocell alarm relay is energized whenever the photocell or SW3 is on. This relay will allow the customer to monitor the modes of operation to determine if switch from day to nightmode has occurred.

3.6 BLEEDER CIRCUIT

The bleeder circuit is the most important safety item in this system. It consists of resistor R32 connected to the high voltage storage capacitor through relay K2. When the AC line voltage is turned off, relays close allowing the resistors to discharge the high voltage stored in the capacitor bank below 50V in 30 seconds.

D-1LVS CONTROLLER

*****CAUTION*****

NEVER RELY ON THIS CIRCUIT TO RENDER THIS SYSTEM HARMLESS. ANY DEFECT IN THIS CIRCUIT COULD ALLOW A HAZARDOUS HIGH VOLTAGE CHARGE TO REMAIN ON THE STORAGE CAPACITORS. ALWAYS WAIT AT LEAST 30 SECONDS AFTER POWER HAS BEEN TURNED OFF BEFORE STARTING ANY WORK ON THIS SYSTEM. ALWAYS MEASURE THE VOLTAGE ON THE STORAGE CAPACITORS WITH A VOLTMETER BEFORE STARTING ANY OTHER WORK ON THIS SYSTEM. NEVER ATTEMPT TO DEFEAT THE SAFETY INTERLOCKS.

3.7 STROBE DIAGNOSTIC CIRCUITS

The diagnostic circuit is provided as a means of making system checks and maintenance more convenient. This circuit is entirely contained on the printed circuit boards PCB #1 and PCB #2. The circuits that are contained on PCB #1, and PCB #2 are as follows:

3.7.1 Control Power On

Line from the 120V AC input is sent through safety switches CSS and BSS isolation transformer T2, fuse F3, and relay K1 to PCB #1. Once this voltage is at PCB #1, it is sent to a step down transformer and is rectified then sent to LED4 (D15). If for any reason power is interrupted, (beacon opened, controller door open, blown F3 fuse, failed relay, etc.) LED4 would be extinguished.

3.7.2 High Voltage

The Cathode side of the high voltage HV is routed through current limiting resistor. When the unit is in daymode, D14 will be at full brightness when the capacitors are at full charge, but dims with the discharging of the storage capacitors. A constant intensity indicates that high voltage is present but capacitors are not discharging (check other indicators for fault). When the red LED fails to glow, then high voltage is no longer present.

3.7.3 Trigger Voltage

The trigger voltage from fuse F2 (CT1A) is sent to current limiting resistor R30 and LED6 (D20). Under normal circumstances, the red LED should be at full intensity indicating voltage to be normal. An absence of this indication means that the voltage is no longer present.

D-1LVS CONTROLLER

3.7.4 Nightmode

Output voltage from the photocell (SSR) is connected to the coil of relay RLY1. Whenever the photocell senses darkness or switch SW3 is on, relay RLY1 will energize thereby sending 12V to the timing circuit as well as to LED7, letting LED7 (D7) glow a constant red.

3.7.5 Primary Timing

The primary timing pulses are received at LED8 (D3). LED8 will flash according to the pulses received from the timing circuit. If LED8 fails to flash, then the primary timing circuit has failed. Check LED9 for secondary timing operation. The strobe unit should produce 40 (+/-2) pulses per minute.

3.7.6 Timing Signal Verify

Timing pulses (either primary or secondary) are received at LED9 (D28). The LED will flash according to the pulses received from the timing circuit, but should be 40 +/-2 FPM. In the unlikely event that this LED is out, then total timing failure has occurred.

3.7.7 Flash Verified

Current from the Cathode side of the flashtube (FTC) is sent through the current sensing transformer T1 on PCB #1. T1 will send a pulse to the gate of the SCR's Q2 and turns it on. Capacitor C11 via Q2 will send voltage to LED5 (D8). After each confirmed flash, LED 5 will blink. Absence of a blinking LED signifies that strobe beacon has ceased to flash.

3.7.8 Strobe Fail Test

Switch S1, when turned on, cuts off the timing signal to the trigger circuit and illuminates LED2 (D25). At this time a strobe alarm should be received at J2. The normal position of S1 is off (switch upward).

D-1LVS CONTROLLER

4.0 TROUBLE SHOOTING

Much of the trouble shooting of this system will consist of correcting a “beacon out” situation. There may also be a failure mode where the flashtube is still flashing, but at the wrong rate or the wrong intensity.

You must study and understand the safety messages and the theory of operation before attempting any service on this system. Servicing this system must be done by qualified personnel only.

*****WARNING - HIGH - VOLTAGE*****

THIS SYSTEM OPERATES AT HIGH VOLTAGE LEVELS THAT COULD BE LETHAL TO SERVICE PERSONNEL. ALL INSTALLATION AND MAINTENANCE WORK SHOULD BE DONE BY QUALIFIED SERVICE PERSONNEL. READ AND UNDERSTAND THE THEORY OF OPERATION AND ITS SAFETY MESSAGES BEFORE ATTEMPTING INSTALLATION OF THIS SYSTEM. DO NOT ATTEMPT TO DEFEAT THE INTERNAL SAFETY DEVICES.

4.1 TOOL REQUIREMENTS

In order to be prepared to troubleshoot or repair this system, a minimum amount of tools and equipment will be required. A recommendation list includes:

- 1) 5/16 Electrician's Screwdriver
- 1) Nut Drivers or Socket Set
- 1) Multi meter - Analog or Digital 600V AC/600V DC Minimum

4.2 DIAGNOSTIC EVALUATION

The first step in troubleshooting of this system or performing annual maintenance will require the technician to open the controller door. With the power off to the controller, the technician should look over the controller circuit and repair or replace any apparent problems such as loose wire connections or corroded terminations. After the initial visual checks have been completed, restore power to the controller and pull out on the plunger of the cabinet safety switch (CSS) located at the lower right edge of the enclosure. Observe at this time the LEDs located on PCB #1 and PCB #2. Determine by observation of these LED indicators if the controller is performing to normal operation.

D-1LVS CONTROLLER

LEDs on PCB #1 are numbered from top to bottom 1-9. LEDs on PCB #2 are numbered from top to bottom D14 - D16. The following chart will indicate normal LED operation.

INDICATOR	OPERATION	NORMAL STATUS
LED 1	Flash Verify 2	N/A
LED 2	Strobe Fail Test	Normal OFF/Flashes in Test Mode
LED 3	Flash Verify 1	Blinks
LED 4	Control Power ON	Steady ON
LED 5	Flash Verify 3	N/A
LED 6	Trigger Voltage	Steady ON
LED 7	Nightmode	Steady ON During Nightmode Operation
LED 8	Primary Timing	Flashing
LED 9	Timing Verify	Flashing
D11	High Voltage #1	Steady ON when Voltage Above 50V DC
D12	High Voltage #2	N/A
D13	High Voltage #3	N/A

4.3 TROUBLE SHOOTING ASSISTANCE

4.3.1 Flash Verify LED - Out

4.3.1.1 Observe high voltage LED on the same beacon circuit to determine if it is available. If the LED is dim or out completely, then check high voltage capacitor bank for a short. If no capacitor is found to be shorted, check the resonant cap for a short. If the resonant cap is okay, replace PCB #2. If the LED is at full illumination, go to the next step.

4.3.1.2 Check the status of the trigger LED. If LED is dim or off, check fuse F2. If blown, replace with exact type of fuse. If the fuse blows again, replace PCB #1. If LED is okay, go to the next step.

4.3.1.3 If steps 4.3.1.1 and 4.3.1.2 check out okay, relamp the beacon.

4.3.2 Control Power On LED - Out

Check interlock circuit for an open circuit. If open, make the necessary repairs. If okay, check fuse F3. Replace if bad.

4.3.3 Primary Timing LED Out

Observe the status of the timing LED. If the LED is dim or out completely, check LED9, if dim or out, replace PCB #1. If one or both are lit, you should have timing.

D-1LVS CONTROLLER

4.3.4 False or Nonexistent Beacon Alarms

- 4.3.4.1 If alarms trip when the system appears to be working normally or fails to show an alarm when there is an obvious failure, replace PCB #1.
- 4.3.4.2 The time delay between an actual failure and the point where the relay trips is preset at the factory at about eight (8) seconds. This delay period can be tested by throwing “on” switch S1 (on the circuit board #1). When this switch is in the alarm test mode, the test mode indicator (LED2) will be illuminated or blinking slightly.

D-1LVS CONTROLLER

*****WARNING - HIGH - VOLTAGE*****

THIS SYSTEM OPERATES AT HIGH VOLTAGE LEVELS THAT COULD BE LETHAL TO SERVICE PERSONNEL. ALL INSTALLATION AND MAINTENANCE WORK SHOULD BE DONE BY QUALIFIED SERVICE PERSONNEL. READ AND UNDERSTAND THE THEORY OF OPERATION AND ITS SAFETY MESSAGES BEFORE ATTEMPTING INSTALLATION OF THIS SYSTEM. DO NOT ATTEMPT TO DEFEAT THE INTERNAL SAFETY DEVICES.

5.0 MAINTENANCE GUIDE

5.1 FLASHTUBE REPLACEMENT

The only required maintenance needed to be performed is the replacement of the flashtubes every two (2) years. By following these instructions, maximum safety and performance can be achieved.

5.1.1 Loosen the wing nut on each latch pin so that it can recline.

5.1.2 Open the lens and tilt it back.

ALWAYS WAIT AT LEAST 30 SECONDS AFTER OPENING THE BEACON BEFORE STARTING ANY WORK ON THE BEACON.

5.1.3 Loosen the three (3) socket screws with a screwdriver to remove lamp.

5.1.4 Install the new flashtube making sure that the red marked pin is aligned with the red wire on the socket. Make sure tube is flush on all socket lugs.

5.1.5 Tighten the socket screws snug, then 1/4 turn more.

5.1.6 Close the lens - make sure nothing hampers safety interlock action.

5.1.7 Re-tighten the three (3) wing nuts on the beacon.

5.2 POWER SUPPLY

No scheduled maintenance is required. Perform on an as needed basis only.

5.3 PHOTOCELL

The photocell is a sealed unit. No maintenance is needed or required other than

D-1LVS CONTROLLER

replacement as necessary.

D-1LVS CONTROLLER

6.0 MAJOR COMPONENTS PARTS LIST

SCHEMATIC TAG #	DESCRIPTION	TWR PART #
BSS1	BEACON SAFETY SWITCH	STJ02003
C103 - C109	40uf 1KV CAP	STB99006
C102	3uf 660V AC CAP	STB99008CSI
C101	4uf 660V AC CAP	STB99005
CSS	CABINET SAFETY SWITCH	STJ02001
F1	10 amp FUSE	KTK10
F2	1/8 amp FUSE	FLQ 1/8
F3	.5 amp FUSE	FUSE .5
FT	FLASHTUBE	STFLSHTB5
K5	DPDT OCTAL RELAY	KRPA11AG120
K6	SPDT OCTAL RELAY	X9KE
K1, K4	DPDT OCTAL RELAY	X99KE
K2	HV BLEEDER RELAY	STJ10006
L1	INDUCTOR	INDCTR3001
L11	BURSTING CHOKE	100273
MOV1, MOV2	METAL OXIDE VARISTOR	MOV524V15
MOV3	METAL OXIDE VARISTOR	V1000LA80A
P1	15 POSITION PLUG	STT60009
PCB #1	D-1LVS CONTROL PCB	STH01226B
PCB #2	HIGH VOLTAGE RECTIFIER PCB	STH02226A
PCB #3	RELAY PCB	STH03226
PHOTOCELL	120V AC PHOTOCELL	P2455L
R31	150 ohm 100W	STA08018
R32	35K 20W	STA08015
R33	2.4 MEG 2W	STA08010
SW3	SPDT 10 amp SWITCH	STJ01002
T2	ISOLATION TRANSFORMER	STC05004
T1	FERRORESONANT	STC30018

C:\Documents and Settings\esalazar\Local Settings\Temporary Internet Files\OLK19\D-1LVS Rev 040903.doc
5/19/2003

12/98; Rev. 6/99; Rev. 03/00; Rev. 05/00;
Rev. 07/07/00 (dwg H01-226B); Reg. 07/08/00 (Pg. 9, DSI);
Rev. 07/00 (o2L/H); Rev. 10/18/00 (retyped & o2-dwgs.)
Rev. 05/14/01 (revised pg 1 – mounting width; warranty & return policy)
Rev 03/20/03 (TWR logo – Dwgs) Rev 04/09/03


D-1LVS CONTROLLER

SCHEMATIC TAG #	DESCRIPTION	TWR PART #
	TRANSFORMER	
T4	TRIGGER TRANSFORMER	STC05005
TB1	10 PART TERM BLK	TERMBLK - 10
TB2	12 PART TERM BLK	TERMBLK 141 - 12
TLS	THERMAL LIMITING SWITCH	STJ10008
	STROBE BEACON	STBEACON7
	STROBE BEACON LENS	STDBCLENS
	BEACON GASKET	STBEAGSK2

D-1LVS CONTROLLER

7.0 RECOMMENDED SPARE PARTS LIST

QUANTITY	PART NUMBER	DESCRIPTION
1	STH01226B	D-1LVS PRINTED CIRCUIT BOARD
1	STJ10006	DPDT CONTACTOR RELAY
1	STFLSHTB5	STROBE FLASHTUBE
1	P2455L	PHOTOCELL
2	KTK10	10 amp FUSE
2	FLQ18	1/8 amp FUSE
2	FUSE .5	1/2 amp FUSE
1	X9KE	SPDT RELAY
2	X99KE	DPDT RELAY



D-1LVS WIRING DIAGRAM

L-865 MEDIUM INTENSITY STROBE

TWR Lighting, Inc.

APP'D

ENGINEER

CHK'D BY

DRAWN BY

E.A.SALAZAR

SHEET SIZE

B

SHEET QTY.

1 OF 1

DATE

12/07/98


SCALE

N.T.S.

DRAWING NO.

M01-283

NOTICE: This drawing is the property of TWR Lighting, Inc. All information contained herein that is not generally known shall be confidential except to the extent the information has been previously established. This drawing may not be reproduced, copied or used as the basis for manufacture or sale without written permission.



ITEM #

DESCRIPTION


- 1 BEACON L-865 WHITE MEDIUM INTENSITY STROBE
- 2 POWER SUPPLY D-1LVS
- 3 WATER TIGHT CABLE CONNECTOR WITH SEALING GLAND.
- 4 MEYERS HUB 3/4"
- 5 MEYERS HUB 1"
- 6 STROBE CABLE (REFER TO DRAWINGS 500-12 FOR PROPER INSTALLATION).
- 7 #P2455L PHOTOCELL

SIDE VIEW

NOTES:


- A POWER SUPPLY IS NORMALLY MOUNTED AT GROUND LEVEL ON TOWER. IT CAN ALSO BE MOUNTED INDOORS. RECOMMENDED MOUNTING HEIGHT IS 48" TO BOTTOM OF THE ENCLOSURE FOR EASE OF MAINTENANCE.
- B MOUNT BEACON HINGES SO LENS WILL OPEN UNOBSTRUCTED BY STRUCTURE.
- C POWER SUPPLY DETAIL FOR L-865 MODEL NO. D-1LVS LIGHTING CONTROLLER.

<u>HOUSING DETAILS D-1LVS</u>			
<u>L-865 MEDIUM INTENSITY STROBE</u>			
<i>TWR Lighting, Inc.</i>			
APP'D		ENGINEER	CHK'D BY
DRAWN BY		E.A.SALAZAR	SHEET SIZE
			B
DATE		SCALE	SHEET QTY.
12/07/98		N.T.S.	1 OF 1
		DRAWING NO.	
		HDO-283	
NOTICE: This drawing is the property of TWR Lighting, Inc. All information contained herein that is not generally known shall be confidential except to the extent the information has been previously established. This drawing may not be reproduced, copied or used as the basis for manufacture or sale without written permission.			



- NOTES:
1. THIS CONTROLLER CAN BE MOUNTED INDOOR OR OUTDOOR.
 2. IT IS HIGHLY RECOMMENDED TO MOUNT A LIGHTING ROD AT THE TOP LEVEL.

D-1LVS INSTALLATION GUIDELINE			
TWR Lighting, Inc.			
APP'D	ENGINEER	CHK'D BY	
DRAWN BY	E.A.SALAZAR	SHEET SIZE	SHEET QTY.
DATE	10/07/98	SCALE	N.T.S.
		DRAWING NO.	INS-283
NOTICE: This drawing is the property of TWR Lighting, Inc. All information contained herein that is not generally known shall be confidential except to the extent the information has been previously established. This drawing may not be reproduced, copied or used as the basis for manufacture or sale without written permission.			



ITEM	QTY.	DESCRIPTION
1	1	PHOTOCELL
2	2	6-32 x 7/8" SCREW
3	1	RECEPTACLE SOCKET
4	3	.250 SPADE CONNECTOR
5	1	RECEPTACLE GASKET
6	1	RECEPTACLE HOUSING
7	1	1/2" CONDUIT LOCKNUT
8	1	3/4" TO 1/2" REDUCER


- NOTES:
- 1. ITEM #8 CAN BE USED TO REDUCE 3/4" CONDUIT TO 1/2" CONDUIT AT THE HOUSING OR AT THE CONTROLLER ITSELF.
 - 2. IF ADDITIONAL WIRE IS REQUIRED OVER THE FACTORY 20', USE THE FOLLOWING CHART.
21' TO 300' - 16 AWG TFFN
301' TO 500' - 14 AWG TFFN

PHOTOCELL HOUSING DETAIL

TWR Lighting, Inc.

APP'D	ENGINEER	CHK'D BY
DRAWN BY E.A.SALAZAR		SHEET SIZE B
DATE 10/18/95		SHEET QTY. 1 OF 1
SCALE N.T.S.		DRAWING NO. 100239

NOTICE: This drawing is the property of TWR Lighting, Inc. All information contained herein that is not generally known shall be confidential except to the extent the information has been previously established. This drawing may not be reproduced, copied or used as the basis for manufacture or sale without written permission.



BILL OF MATERIALS			
ITEM NO.	QTY.	TWR PART NO.	DESCRIPTION
1	1	STBEACON7	LVS STROBE BEACON
2	1	STH40283	D-1LVS (LOW VOLTAGE CONTROLLER)
3	-	STCABLTIE	PRT5EH-CO PANDUIT CABLE TIE(EVERY 5')
4	-	STROBCABLE2	6 CONDUCTOR CABLE (TWR HT. + 30'/9M)
5	2	CABLGRIP1	SINGLE EYE LACE MESH .5 - .62

* = ITEMS NOT SHOWN

NOTES:

- 1) POWER SUPPLY IS NORMALLY MOUNTED AT EYE LEVEL ON TOWER. IT CAN ALSO BE MOUNTED INDOORS. RECOMMENDED MOUNTING HEIGHT IS 42" TO BOTTOM OF ENCLOSURE FOR EASE OF MAINTENANCE.
- 2) MOUNT BEACON HINGE SO LENS WILL OPEN UNOBSTRUCTED BY STRUCTURE.
- 3) ON AM TOWER APPLICATIONS, KEEP GROUND LUG FROM BEING CONNECTED TO EARTH GROUND.
- 4) STROBE CABLE IS TO BE FASTENED TO TOWER STRUCTURE W/PART NUMBER STCABLTIE.(ATTACH EVERY 5')
- 5) THIS DRAWING IS PROVIDED AS A GENERAL REFERENCE. TWR LIGHTING, INC. DOCUMENTATION SUPERCEEDS THIS DRAWING & SHOULD BE REVIEWED PRIOR TO INSTALLATION OF THIS SYSTEM.

LK1D1LVS TOWER LIGHTING KIT
(CABLE RUN FOR 200'/61M TO 350'/107M TOWERS)

TWR Lighting, Inc.

APP'DENGINEERCHK'D BY

DRAWN BYE.A.SALAZARSHEET SIZEB1 OF 1


DATE12/07/98SCALEN.T.S.DRAWING NO.500-12

12/30/98(B)CHG. TXT ON WIRE


12/16/98(A)CHG. CONTROLLER

DATELTR.REVISION

NOTICE: This drawing is the property of TWR Lighting, Inc. All information contained herein that is not generally known shall be confidential except to the extent the information has been previously established. This drawing may not be reproduced, copied or used as the basis for manufacture or sale without written permission.




SETTINGS:




D-1LVS CONTROL PCB#1			
L-865 MEDIUM INTENSITY STROBE			
TWR Lighting, Inc.			
APP'D	ENGINEER	CHK'D BY	
DRAWN BY E.A.SALAZAR		SHEET SIZE B	SHEET QTY. 1 OF 1
DATE 6/15/95	SCALE N.T.S.	DRAWING NO. H01-226B	
NOTICE: This drawing is the property of TWR Lighting, Inc. All information contained herein that is not generally known shall be confidential except to the extent the information has been previously established. This drawing may not be reproduced, copied or used as the basis for manufacture or sale without written permission.			

07/07/00	(E)	ADDED NOTES
DATE:	LTR.	REVISION



05/13/03		UPDATED DWG
DATE:	LTR.	REVISION

HIGH VOLTAGE RECTIFIER PCB			
TWR Lighting, Inc.			
APP'D		ENGINEER	
DRAWN BY		CHK'D BY	
E.A.SALAZAR		SHEET SIZE	SHEET QTY.
DATE		SCALE	DRAWING NO.
11/07/98		FULL	A 1 OF 1 H02-226A
NOTICE: This drawing is the property of TWR Lighting, Inc. All information contained herein that is not generally known shall be confidential except to the extent the information has been previously established. This drawing may not be reproduced, copied or used as the basis for manufacture or sale without written permission.			




D-1LV RELAY PCB

TWR Lighting, Inc.

APP'D	ENGINEER	CHK'D BY
DRAWN BY	E.A.SALAZAR	SHEET SIZE A
DATE	07/24/97	SHEET QTY. 1 OF 1
SCALE	N.T.S.	DRAWING NO. H03-226

05/13/03	B	E.A.S.	UPDATED PCB
DATE:	LTR.		REVISION

NOTICE: This drawing is the property of TWR Lighting, Inc. All information contained herein that is not generally known shall be confidential except to the extent the information has been previously established. This drawing may not be reproduced, copied or used as the basis for manufacture or sale without written permission.



BILL OF MATERIALS			
ITEM NO.	QTY.	TWR PART NUMBER	DESCRIPTION
1	1	121102013	DB QUICK OPEN SCREW FLAT
* 2	.5'	16AWGBLK	#16AWG BLACK TEFLON WIRE
3	7	525B	BUCHANNAN
4	1	530B	BUCHANNAN END SECTION
5	1	INDCTRC3001	INDUCTOR
6	1	STC05005	TRIGGER TRANSFORMER
7	1	INSULATOR	CERAMIC INSULATOR
8	3	BU27200	FLASHTUBE SOCKET INSERT
* 9	4"	HEATSHRINK2	1/2" GLUE LINED HEAT SHRINK
10	4	1032X38PHH	10-32 x 3/8" PHILLIPS BINDER HEAD SCREW
11	4	832X14PHH	8-32 x 1/4" PHILLIPS PAN HEAD SCREW
12	2	632X38PHH	6-32 x 3/8" PHILLIPS PAN HEAD SCREW
13	8	1032X38SCSS	10-32 x 3/8" S.S. PHILLIPS PAN HEAD SCREW
14	2	18RAD18277	T & B CONNECTOR
15	1	STBEAGSKT	GASKET, NEOPRENE, 13-1/4" x 15"
* 16	11	TY223M	HI TEMP TY WRAPS T&B
17	1	STDBCLENS	CLEAR DB LENS
18	1	STCONLAB2	PRODUCT LABEL DWG #100223
19	8	18PRSS-2	1/8 x 0.40 SS.S. POP RIVET #44
20	1.75'	7X7SS	1/16 7x7 S.S. WIRE
21	1	2-10000	2-1000000 CIRCULAR SPIRIT LEVEL
22	2	14FWDB	1/4 FW CH16L 18-8 0.265 ID/5
23	1	STBFRAMKIT	SHORT STROBE BEACON FRAME KIT
23A	2	100337	DUAL BEACON LENS RETAINER
23B	6	100368	DUAL BEACON CAP BRACKET
23C	1	100396	INDUCTOR BRACKET
23D	1	100344	CAP DUAL BEACON
23E	1	100342	DUAL BEACON UPPER HINGE
23F	1	100393M	DUAL BEACON BASE
* 24	1'	18AWG BLU	18AWG BLUE WIRE, TEFLON
* 25	1'	18AWG BRN	18AWG BROWN WIRE, TEFLON
26	1	121340712	DB QUICK OPEN CAPTIVE S. W/FIBER WASHER
* 27	8	8NFW	#8 NYLON FLAT WASHER
28	2	14X34CLVP	1/4" x 3/4" SHORT CLEVIS PIN
29	2	12SSCP	1/2 S.S. COTTER PIN
30	1	1261	12-6-1 S.S. CAPTIVE SCREW
31	1	STJ02003	CHERRY SWITCH
* 32	.5'	16AWG RED/BLK	M16878/5 16AWG TEFLON TYPE EE
33	1	EL190S	1" 90° SHORT ELBOW GALVANIZED
34	1	CGB395SA	1" CORD CONNECTOR 0.5 TO 0.625
* 35	1.25'	HEATSHRINK1	1/4" GLUE LINED BLACK HEAT SHRINK
36	1	100394-02	INDUCTOR BOTTOM PAD GASKET
37	1	STFLSHTB5	FLASHTUBE LV
* 38	1	A315	1" CONDUIT LOCKNUT, GALVANIZED
39	4	58X112	A325 5/8" x 1-1/2" WITH ANCO L/N
* 40	1	CSL062X100	1/16 COPPER SLEEVE
41	3	1032X12SCSS	FLASHTUBE SOCKET INSERT SCREW
42	3	1032FW	#10 FLAT WASHER
43	3	832NUT	8-32 NUT
44	3	832X114PHH	8-32 x 1-1/4" PHILLIPS PAN HEAD SCREW
45	1	STBEAGSK2	NEOPRENE GASKET, 3/16" x 15-1/4"
46	1	100319	DUAL BEACON FLASHTUBE SOCKET
47	3	1032X12PHH	10-32 x 1/2" PHILLIPS PAN HEAD
48	2	832X12PHH	8-32 x 1/2" PHILLIPS PAN HEAD
49	1	832X38PHHN	8-32 x 3/8" PHILLIPS PAN HEAD NYLON SCREW
* 50	3	TV18-12PT-1	20AWG ISOLATED FERROLE

* = ITEMS NOT SHOWN

NOTE:
1. ITEM #23A-23F SOLD AS AN ASSEMBLY ONLY.
ORDER ITEM PART #STBFRAMKIT.

STBEACON7

STROBE BEACON DETAIL
L-865 MEDIUM INTENSITY

TWR Lighting, Inc.

APP'D	ENGINEER	CHK'D BY
DRAWN BY E.A.SALAZAR	SHEET SIZE B	SHEET QTY. 1 OF 1
DATE 12/07/00	SCALE N.T.S.	DRAWING NO. 100437M

NOTICE: This drawing is the property of TWR Lighting, Inc. All information contained herein that is not generally known shall be confidential except to the extent the information has been previously established. This drawing may not be reproduced, copied or used as the basis for manufacture or sale without written permission.

DATE: 03/23/01	LTR. (C)	REVISION
----------------	----------	----------