



PARTS LIST FOR #55G GUYED TOWERS
90 MPH Basic Wind Speed (No Ice)

Tower Height	55G	BPC55G w/3/4X12PP	APL55G	SA253UA	GA55GD	G.W. 3/16 EHS	G.W. 1/4 EHS	G.W. 5/16 EHS	BG2142	BG2144	BG2146	5/16 THH	3/8 THH	7/16 THH	3/8TB&E	1/2TB&J	5/8TB&J	GAC 303	GAC345501	GAC565501	AGKE	BGKE
220'	22	1	1	3	6	1925'	800'	900'	24	6	6	24	6	6	6	9	3	3	3		2	2
230'	23	1	1	3	6	2000'	850'	925'	24	6	6	24	6	6	6	9	3	3	3		2	2
240'	24	1	1	3	7	2600'	900'	1000'	30	6	6	30	6	6	9	9	3	3	3		2	2
250'	25	1	1	3	7	2700'	925'	1025'	30	6	6	30	6	6	9	9	3	3	3		2	2
260'	26	1	1	3	7	2825'	1000'	1050'	30	6	6	30	6	6	9	9	3	3	3		2	2
270'	27	1	1	3	8	3625'	1025'	1100'	36	6	6	36	6	6	9		15	3		3	2	2
280'	28	1	1	3	8	2850'	2325'	1150'	30	12	6	30	12	6	9		15	3		3	2	2
290'	29	1	1	3	8	2925'	2350'	1175'	30	12	6	30	12	6	9		15	3		3	2	2
300'	30	1	1	3	8	3175'	1000'	2350'	30	6	12	30	6	12	9		15	3		3	2	2

Items shown above are necessary for a complete "ground" guyed tower. (Note: Cable clamps and extra wire have been provided for turnbuckle safety requirements.)

Anchor grounding (AGKE) kit, along with appropriate ground clamps, and base grounding (BGKE) kits, as recommended by EIA, are included with the tower material.

Installation information and a safety package (part number ACWS) are also included with the tower material. The safety package consists of one anti-climb warning sign and two Danger - Watch for Wires labels along with other printed safety information.

All types of antenna installations should be thoroughly inspected by qualified personnel and re-marked with hazard and warning labels at least twice a year to insure safety and proper performance.